


# ASSEMBLY

## Edison Workbench Straight & Corner Screen



View Digitally

# Important Safety Instructions

This product is for commercial use only.

Maximum intended load for each worksurface is 200 lbs (91 kg)

When using an electrical furnishing, basic precautions should always be followed, including the following: Read all instructions before using (this furnishing).

---

## DANGER

To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning.

---


## WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Do not use outdoors.
7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
8. To disconnect, turn all controls to the off position, then remove the plug from outlet.
9. Risk of Electric Shock – Connect this furnishing to a properly grounded outlet only. See Grounding Instructions (Fig. 1).
10. Mount furnishings at the correct height.

### Grounding Methods

(Fig. 1)



## If Using Optional Utility Power -


1. The electrical desk plug must be plugged into the utility power when present.
2. This product is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated in sketch A (see Figure 77.1). Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.

---

## Save These Instructions


**OPERATING INSTRUCTIONS** – Please refer to the provided Installation Instructions and User Guide.

**POLARIZED PLUG INSTRUCTIONS** – To reduce the risk of electric shock, this furnishing has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

**SERVICING OF DOUBLE-INSULATED PRODUCTS** – In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace. A double-insulated product is marked with the words “DOUBLE INSULATION”, “DOUBLE INSULATED”, or .

This product is for use on a nominal 120-V circuit. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.


## Tools



Electric Drill

Additional tools such as a 90 Degree Bit and an 18” Extension are helpful for some steps.

\*No torque or ball bits should be used



90 DGREE BIT



18” EXTENSION



Phillips Drill/  
Driver Bit



4mm Hex Drill/  
Driver Bit



3mm Hex Drill/  
Driver Bit




R2 Square  
Drill/Driver Bit



Flat Head Drill/  
Driver Bit

# Hardware

## Straight Screen



(0000229)  
Glide 5/16-18 x 1"  
Screw Slot




(0000238)  
#8 x 1-3/4" Square Drive  
Thread Cutting Screw



(125285 Black)  
(125290 Silver)  
M6-1.00 x 12MM Button  
Head Screw

---

## Corner Screen



(0000229)  
Glide 5/16-18 x 1"  
Screw Slot




(0000238)  
#8 x 1-3/4" Square Drive  
Thread Cutting Screw





(122800)  
#10 x 5/8"  
Truss Head Screw

# Essential Components

## Straight Screen




Desk Screen





Mounting Bracket

---


## Corner Screen



Corner Screen




Mounting Bracket



Pencil Cup



Hook



Medallion Bracket





# Straight Screen

## 1. Insert Clamping Glides into Mounting Brackets.

Place each Clamping Glide into threaded hole in each Mounting Bracket as shown (1a).

Tighten each Clamping Glide by turning clock-wise (1b).



Position the head of the Clamping Glide at least 1-1/8" from the top of the Mounting Bracket (1c). **DO NOT** over-tighten.




## 2. Secure Brackets to Straight Screen

Position Mounting Brackets to align mounting pilot holes on Straight Screen (2a).


Attach each Mounting Bracket to Straight Screen using two (2) button head screws per Mounting Bracket (2b).



- 3. Align Desk Screen to Worksurface.**  
Align Straight Screen and Mounting Brackets to worksurface making sure Mounting Brackets are secured.







**Side View**



- 4. Attach Straight Screen to Worksurface.**  
Using a flathead screwdriver, tighten each Clamping Glide by turning clock-wise (4a).

If the Bench has a profile or Knife edge, secure with two (2) screws per Mounting Bracket (4b). Repeat steps 1 thru 4 to install remaining Straight Screen.







# Corner Screen

## 1. Insert Clamping Glides into Mounting Brackets.

Place each Clamping Glide into threaded hole in each Mounting Bracket as shown (1a).


Tighten each Clamping Glide by turning clock-wise (1b).

Position the head of the Clamping Glide at least 1-1/8" from the top of the Mounting Bracket (1c). **DO NOT** over-tighten.




## 2. Align Mounting Brackets to Worksurface.





Position the Mounting Brackets on the back edge of the worksurface. Position should be based on Corner Screen width and on the desired side of the worksurface.




Side View




- 3. Secure Mounting Brackets to Worksurface.**  
 Using a flathead screwdriver, tighten each Clamping Glide by turning clock-wise (3a). If the Bench has a profile or Knife edge, secure with (2) screws per Mounting Bracket (3b).



- 4. Align Corner Screen to Worksurface.**  
 Lower the fabric portion of the Corner Screen into the Mounting Brackets.




**Side View**





- 5.** Insert the Medallion Bracket through the bottom slot in the metal portion of the Corner Screen and align it with the rear edge of the worksurface support rail.



- 6. Secure the medallion.**  
Secure the Medallion Bracket in place using two (2) screws. Repeat steps 1 thru 5 (Corner Screens) to install remaining Corner Screen.

